


## **DRAWINGS**

There is attached 34 sheets of drawings.








F16.2




F16.5








F16.9




F16.10





F1611

530, attach ring 526 Skm just Wert aux 16.12 ring 526 ring 526 ring 526 width 530 width




F16.14





F16.18




F16.19


1000 -


1002 wide Angle mode (ON trigger) apture mage 1004 i.e. of condition -1006 locate license plate onimage 200M -1008 capture image -1010 Extract late data Communicate 1012 data to remote computer \* Communicate 1014 condition or situation \* Receive instr. 1016 from remote System

F16.20





F14,21







£ 1260 Controls -1 Take Reading - + Front or to Back Dave Reading leaded memory O Erase a Reading
O Replace a reading O Store written text F16. 29 Reading display Scratch Pad E 1272 activate 8'10 7/8"/ 8-e Yaker - Select - mode Ø1 € CLR Ø **0**2 **0**3 6 4 0 NV RSTO miz 1274 1210 1266 F16.30









F16.34





F14.35







F14.38









F16,42




## ×1700







F16,45




F16.46








F16.48



F16.49







F16.55

